

FV1 FULL FACE VISOR INSTALLATION INSTRUCTIONS STEP BY STEP

- 1) SPACER CLIPS SHOULD BE PLACED POINTING DOWN, WITH FLAT/THICKER SIDE AGAINST HELMET:



- 2) POSITION VISOR FLIPPED UP/OPEN, WITH FLAT/THICKER SIDE OF SPACER CLIPS AGAINST TOP OF HELMET; ALIGN CLIPS WITH SCREW HOLES AS SHOWN:



- 3) SIMPLY SCREW IN EACH SCREW PROVIDED THROUGH SPACER CLIP, WHILE KEEPING VISOR FLIPPED OPEN/UP:



4) VISOR CAN NOW BE CLOSED AND SPACER CLIPS SHOULD LOOK LIKE THIS (POINTING DOWN):



WHEN INSTALLED CORRECTLY, SPACER CLIPS CAN BE SQUEEZED AND SCREW IS LONG ENOUGH TO EXTEND PAST THE CLIP AND HAVE ENOUGH THREAD TO SCREW INTO HELMET:



NOTE: IF YOU TRY TO INSTALL VISOR WHILE CLOSED, WITH SPACER CLIPS FLIPPED UP AS SHOWN BELOW, THE SCREWS WILL NOT BE LONG ENOUGH TO INSTALL VISOR CORRECTLY – PLEASE FLIP VISOR OPEN, POINT SPACER CLIPS DOWN AND SCREW IN FROM THE ‘INSIDE’ AS DETAILED ABOVE:

